



GUIDE TO ASSEMBLING YOUR SUPEX STONE GUARD

PLEASE READ THROUGH THESE INSTRUCTIONS BEFORE BEGINNING ASSEMBLY




The ultimate way to protect your recreational vehicle from stones and hard debris, is this easy to install Stone Guard.

Including:

- Super tough Rip-stop Mesh
- Two heavy-duty rubber Mud Flaps

Note: Ensure that there is significant space between your RV and Stone Guard, to allow for your vehicle's turning circle.
Also ensure enough space for Jockey Wheel handle.




You will receive your Stone Guard flat-packed. It is recommended that you set all components out to check you have received everything.

1. Centre Piece (x1)
2. End Pieces (x1 LH, x1 RH)
3. Reinforcing plates (x4)
4. Rip-stop mesh (x1)
5. Rubber Mud Flaps (x2)
6. Mud Flap Bars (x2)
7. 18mm Threaded self-drilling Screws (x1 bag)
8. 15mm Threaded self-drilling Screws (x1 bag)
9. Mounting kits - including 4x rubber spacers (x2)
10. A-Frame receptors (x2)
11. Locking 'R' pins (x2)

Note: Screws may vary between Hex head and Phillips head. Please alter tools as required

TOOLS REQUIRED (not provided):

1. 5mm Allen Key
 2. Adjustable Shifter (x2)
 3. Hex head/Phillips Screwdriver
- 

ASSEMBLY OF THIS STONE GUARD MUST BE DONE IN A SAFE AREA, FREE OF OBSTRUCTION AND HAZARD

INSTRUCTIONS

STEP 1

Find the Centre Piece and End Pieces.

Slide both End Pieces into each side of the Centre Piece.

Using 18mm self-drilling threaded screws, secure both End Pieces onto each end of the Centre Piece.

The top of the Stone guard is depicted by curved corners.

STEP 2

Fasten Reinforcing Plate to each side of Stone guard frame using 18mm self-drilling threaded screws and washers (supplied).

STEP 3

Turn Stone guard frame over, so its curved downwards, to prepare to add Rip Stop Mesh.

Note: Location of the screws is already indicated with pre-drilled holes in the Stone guard frame.

STEP 4

Place Mesh over Stone guard frame and fasten together using 15mm Threaded screws. Begin at the corners and move along the edges of frame.

Note: As the Mesh Cuff is not pre-drilled, it may be difficult to find the correct hole in the Stone guard frame. To make this easier, mark the Cuff with a pinhole before you permanently fasten it on.

STEP 5

To attach the Mud Flaps, turn Stone Guard over again, so the arc of the frame is curved upwards.

Place first Mud Flap on top of Stone Guard frame, then place Mud flap bar on top of Mud Flap. It is important to ensure that all holes are lined up correctly.

Using 18mm threaded screws, fasten these two components to Stone Guard frame tightly. Repeat on the other side with other Mud Flap and Mud Flap bar.

STEP 6

Now relocate your Stone Guard to the A-Frame of your Caravan/Camper Trailer.

Place Stone Guard over the A-Frame and check that you have clear access to at least 3 of the cut-outs. This will guarantee the most appropriate position for your Stone Guard to sit.

STEP 7

Install U-Brackets onto A-Frame and then secure mounting feet to Stone Guard frame.

Note: If the A-Frame you are using is not the standard thickness that the U-Brackets are designed for, then rubber spaces and varied bottoms are provided to accommodate for different sizes. These do not have to be used if the A-Frame is standard thickness.

STEP 8

Now lift your Stone Guard onto the A-Frame, ensuring that the downward prongs fit into U-Bracket receptors.

STEP 9

To stop the Stone Guard from lifting, lock frame into receptors using the locking pins. If you would like additional security use padlock or cable locks (not provided).

YOUR SUPEX PRODUCTS STONEGUARD IS NOW COMPLETE!





WARRANTY

Please contact Supex Products for Warranty Terms & Conditions.

Please note that these specifications are correct at the time of print, and may change without notice

CONTACT US

11 Lockyer St
Goulburn NSW 2580
Australia

Phone: 1800 805 826
Email: sales@supex.com.au
Web: www.supex.com.au